

# PARTS LIST

PLEASE NOTE: When ordering parts, it is very important that part number and description of part coincide.

INDEX NO.	PART NO.	DESCRIPTION
1	DV-1378	SHROUD TOP
2	DV-1376	SHROUD SIDE RIGHT
3	R-2521	AIR FILTER
4	DV-1375	FILTER RETAINER
5	DV-1379	WALL MOUNTING BRACKET
6	DV-1048	WALL BRACKET - 2 REQUIRED
7	R-2586	CONTROL DOOR PIN - 2 REQUIRED
8	19676	CONTROL DOOR ASSEMBLY
9	DV-1373	CASING TOP
10	DV-1368	BLOWER HOUSING - 2 REQUIRED
11	R-2584	BLOWER WHEEL - 2 REQUIRED
12	R-2573	BLOWER MOTOR
13	R-2598	MOTOR BASE WASHER - 4 REQUIRED
14	R-1279	LIMIT SWITCH
15	DV-1367	INNER TOP
16	R-2546	CONTROL KNOB
17	R-2522	ON/OFF SWITCH
18	19561	JUNCTION BOX
19	DV-1370	JUNCTION BOX COVER
20	R-1995	TRANSFORMER
21	R-6989	PRESSURE SWITCH
22	R-8140	CONTROL BOARD
23	R-2577A	TEMPERATURE CONTROL BOARD
24	DV-1365	CASING WELDED ASSEMBLY
25	R-1468	STRAIN RELIEF BUSHING
26	R-2099	CORD SET
27	DV-1371	INNER END
28	DV-1372	CASING SIDE - 2 REQUIRED
29	15790	COLLECTOR BOX (DV-20E-5 ONLY)
29	15791	COLLECTOR BOX (DV-40E-5 ONLY)
30	R-2519	INDUCER WHEEL
31	DV-1169	INDUCER BLOWER HOUSING
32	R-2523	INDUCER MOTOR
33	15783	EXCHANGER ASSEMBLY (DV-20E)
33	15784	EXCHANGER ASSEMBLY (DV-40E)
34	27523	IGNITOR KIT
37	R-2543	FLAME SENSOR
38	R-2541	BURNER (2 REQUIRED ON DV-40E-5)

INDEX NO.	PART NO.	DESCRIPTION
39	R-2575	FLAME ROLLOUT SWITCH
40	DV-1038	BURNER COMPARTMENT ACCESS PANEL
41	DV-1039	BURNER COMPARTMENT
42	R-3237	GAS VALVE (NAT GAS)
42	R-3238	GAS VALVE (LP GAS)
43	DV-1366	VALVE BRACKET ASSEMBLY
44	DV-1016	MANIFOLD ASSEMBLY (DV-20E-5 ONLY)
44	DV-1013	MANIFOLD ASSEMBLY (DV-40E-5 ONLY)
45	P-88-44	ORIFICE (NAT GAS) - 1 REQUIRED ON DV-20E-5
45	P-88-55	ORIFICE (LPG GAS) - 1 REQUIRED ON DV-20E-5
45	P-88-44	ORIFICE (NAT GAS) - 2 REQUIRED ON DV-40E-5
45	P-88-55	ORIFICE (LPG GAS) - 2 REQUIRED ON DV-40E-5
46	M-148	MANIFOLD GASKET
47	DV-781	OBSERVATION HOLE COVER ASSEMBLY
48	M-155	OBSERVATION HOLE COVER GASKET
49	DV-1040	FRONT SHIELD ASSEMBLY
50	DV-1024	BOTTOM SHIELD
51	DV-1363	FRONT GRILL ASSEMBLY
52	DV-1380	CASING FRONT ASSEMBLY
53	R-2539	HOSE CLAMP - 4 REQUIRED
54	R-3113	INLET HOSE
55	R-3111	OUTLET ELBOW
56	DV-1192	VENT PAN ASSEMBLY
57	R-3114	INLET CAP
58	R-3115	WALL PLATE GASKET - INSIDE
59	R-2587	WALL PLATE GASKET - OUTSIDE
60	DV-1195	WALL PLATE - OUTSIDE
61	DV-1193	TUBE SPACER
62	DV-1194	END CAP ASSEMBLY
63	DV-1377	SHROUD SIDE LEFT
NS	DV-1361	BAFFLE - 1 REQUIRED ON DV-20E-5
NS	DV-1108	Condensate Kit
NS	DV-1132	Elbow Kit
NS	R-8142	WIRE ASSEMBLY - CONTROL BOARD

NS - NOT SHOWN

# PARTS VIEW

