

PARTS LIST

PLEASE NOTE: When ordering parts, it is very important that **part number** and **description** of part coincide.

INDEX NO	PART NO	DESCRIPTION
1	DV1213	TOP PLATE
2	R3165	DOOR CLIP (2 REQUIRED)
3	DV1204	CASING SIDE - RIGHT
4	DV1202	CASING BACK
5	DV1205	CASING SIDE - LEFT
6	DV1249	AIR DROP
7	DV1230	TURBULATOR (3 REQUIRED)
8	DV1233	OUTLET BOX REAR
9	DV1224	OUTLET BOX COVER
10	R3161	FAN BLADE
11	R3166	FAN MOTOR
12	DV1246	MOTOR MOUNTING BRACKET
13	R1536	BUSHING
14	R1499	RUBBER GROMMET (4 REQUIRED)
15	R1454	BRASS BUSHING (4 REQUIRED)
16	R3164	DOOR CLIP (2 REQUIRED)
17	DV1251	INNER SHIELD - RIGHT (INCLUDES NO. 22)
18	R6176	FAN CONTROL SWITCH
19	R3175	LIMIT SWITCH
20	DV1255	INNER SHIELD FRONT (SPP)
20	15666	INNER SHIELD FRONT (IP)
21	DV1253	INNER SHIELD COVER PLATE (2 REQUIRED)
22	DV1252	INNER SHIELD - LEFT (INCLUDES NO. 22)
23	DV1257	EXCHANGER ASSEMBLY
24	R3162	FILTER
25	R3163	FILTER RETAINER
26	R3232	PILOT - NAT (IP ONLY)
26	R3233	PILOT - LPG (IP ONLY)
27	P8861	ORIFICE - NAT (3 REQUIRED)
27	P8861C	ORIFICE - LPG (3 REQUIRED)
28	DV1236	MANIFOLD
29	DV1259	CASING FRONT
30	P112	MANIFOLD UNION
31	R1109	BUSHING (3/8 X 1/2)
31	R9505	BUSHING (1/2 X 3/4) - NAT (IP)
32	R3170	GAS VALVE - NAT (IP)
32	R3171	GAS VALVE - LPG (IP)
32	R2148	GAS VALVE - NAT (SSP)
32	R5655	GAS VALVE - LPG (SPP)
33	R2708	PIEZO IGNITOR (SPP)

INDEX NO	PART NO	DESCRIPTION
34	DV781	OBSERVATION HOLE COVER WITH MICA
35	M155	GASKET - OBS HOLE
36	FF160	PIEZO BRACKET (SPP)
37	DV1240	BURNER COMPARTMENT FRONT
38	DV12655	BURNER COMPARTMENT BODY
39	M147	GASKET - TUBE SEAL
40	DV775	SEAL BRACKET (SPP)
40	DV691	SEAL BRACKET (IP)
41	M156	MANIFOLD GASKET
42	DV1235	PILOT BRACKET (IP)
43	R3031	BURNER (3 REQUIRED)
44	DV1239	BURNER BRACKET
45	UH810	TRANSFORMER MOUNTING BRACKET (SPP)
45	UH452	TRANSFORMER MOUNTING BRACKET (IP)
46	R1995	TRANSFORMER (SPP)
46	R998	TRANSFORMER (IP)
47	UH451	JUNCTION BOX COVER
48	DV572	JUNCTION BOX
49	R1410	BUSHING
50	R690	CORD SET
51	R1515	BUSHING
52	DV1215	BOTTOM PLATE
53	R3034	PILOT - NAT (SPP)
53	R3035	PILOT - LPG (SPP)
54	GWT021	PILOT BRACKET (SPP)
55	R3180	ELECTRODE AND WIRE (SPP)
56	R2256	THERMOCOUPLE - 18" (SPP)
58	DV1273	VENT KIT COMPLETE
59	DV1355	FLUE OUTLET TUBE
60	DV1354	AIR INLET TUBE
61	DV131	OUTSIDE MOUNTING PLATE
62	DV769	VENT CAP
N/S	DV1261	PILOT TUBING
N/S	R1081	PILOT ORIFICE - NAT (SPP)
N/S	R1089	PILOT ORIFICE - LPG (SPP)
N/S	R1233	PILOT ORIFICE - NAT (IP)
N/S	R3265	PILOT ORIFICE - LPG (IP)
N/S	R3172	WIRE HARNESS (SPP)
N/S	R3173	WIRE HARNESS (IP)
N/S	R3236	WIRE (IP)

N/S - NOT SHOWN

USE ONLY MANUFACTURER'S REPLACEMENT PARTS. USE OF ANY OTHER PARTS COULD CAUSE INJURY OR DEATH.

PARTS VIEW

DVC-35 IP
DVC-35 SPP

