

**PLEASE NOTE:** When ordering parts, it is very important that **part number** and **description** of part coincide.

INDEX NO.	PART NO.	DESCRIPTION
1	WFA115	GASKET - HEADER
2	DV1247	TOP PLATE (USA)
2	15668	TOP PLATE (CANADA)
3	R3165	DOOR CLIP (2 REQUIRED)
4	DV1204	CASING SIDE - RIGHT
5	DV1203	CASING BACK
6	DV1205	CASING SIDE - LEFT
7	DV1248	AIR DROP (INCLUDES NO. 54)
8	DV1231	TURBULATOR (3 REQUIRED)
9	DV1250	DIVIDER PLATE
10	DV1234	OUTLET BOX
11	DV1225	OUTLET BOX COVER
12	R3177	VENT SAFETY SWITCH
13	R3161	FAN BLADE
14	R3166	FAN MOTOR
15	DV1246	MOTOR MOUNTING BRACKET
16	R1536	BUSHING (5 REQUIRED)
17	R1499	RUBBER GROMMET (4 REQUIRED)
18	R1454	BRASS BUSHING (4 REQUIRED)
19	R3164	DOOR CLIP (2 REQUIRED)
20	DV1251	INNER SHIELD - RIGHT (INCLUDES NO. 23)
21	R6176	FAN CONTROL SWITCH
22	R3176	LIMIT SWITCH
23	DV1253	INNER SHIELD COVER PLATE (2 REQUIRED)
24	DV1254	INNER SHIELD FRONT (SPP)
24	33416	INNER SHIELD FRONT (IP)
25	R3163	FILTER RETAINER
26	R3162	FILTER
27	DV1252	INNER SHIELD -LEFT (INCLUDES NO. 23)
28	DV1256	EXCHANGER ASSEMBLY
29	DV1235	PILOT BRACKET (IP)
30	R3232	PILOT - NAT (IP)
30	R3233	PILOT - LPG (IP)
31	P8851	ORIFICE - NAT (3 REQUIRED)
31	P8860	ORIFICE - LPG (3 REQUIRED)
32	DV1236	MANIFOLD
33	DV1258	CASING FRONT
34	P112	MANIFOLD UNION
35	R1109	BUSHING (3/8 x 1/2)
35	R9502	BUSHING (3/8 x 3/4) - NAT (IP)

INDEX NO.	PART NO.	DESCRIPTION
36	R5655	GAS VALVE - LPG (SPP)
36	R2148	GAS VALVE - NAT (SPP)
36	R3170	GAS VALVE - NAT (IP)
36	R3171	GAS VALVE - LPG (IP)
37	R2708	PIEZO IGNITOR (SPP)
38	FF160	PIEZO BRACKET (SPP)
39	DV1318	OBSERVATION HOLE COVER PLATE
40	DV1242	BURNER COMPARTMENT FRONT (SPP)
41	DV1237	BURNER COMPARTMENT BODY
42	M148	MANIFOLD GASKET
43	GWT168	AIR SHUTTER FRONT (LPG)
44	GWT169	AIR SHUTTER REAR (LPG)
45	R3031	BURNER (3 REQUIRED)
46	DV1239	BURNER BRACKET
47	UH452	TRANSFORMER MOUNTING BRACKET (IP)
47	UH810	TRANSFORMER MOUNTING BRACKET (SPP)
48	R1995	TRANSFORMER (SPP)
48	R998	TRANSFORMER (IP)
49	UH451	JUNCTION BOX COVER
50	DV572	JUNCTION BOX
51	DV1260	COVER PLATE - AIR DROP
52	R1410	BUSHING
53	R690	CORD SET
54	R1515	BUSHING
55	DV1215	BOTTOM PLATE
56	R3034	PILOT - NAT (SPP)
56	R3035	PILOT - LPG (SPP)
57	GWT021	PILOT BRACKET (SPP)
58	R3180	ELECTRODE AND WIRE (SPP)
59	R2256	THERMOCOUPLE -18" (SPP)
N/S	DV1261	PILOT TUBING
N/S	R1081	PILOT ORIFICE - NAT (SPP)
N/S	R1089	PILOT ORIFICE - LPG (SPP)
N/S	R1233	PILOT ORIFICE - NAT (IP)
N/S	R3265	PILOT ORIFICE - LPG (IP)
N/S	R3172	WIRE HARNESS (SPP)
N/S	R3173	WIRE HARNESS (IP)
N/S	R1587C	VENT SAFETY WIRE ASSEMBLY

N/S - NOT SHOWN

**USE ONLY MANUFACTURER'S REPLACEMENT PARTS. USE OF ANY OTHER PARTS COULD CAUSE INJURY OR DEATH.**

FAW-40 IP  
FAW-40 SPP

