

# PARTS LIST

**PLEASE NOTE:** When ordering parts, it is very important that part number and description of part coincide.

Index No	Part No.	Description
1	WFA115	Baseplate Gasket
2	11763	Outer Casing Top
3	R618	Motor Mount (Four Required)
4	11764	Motor Mounting Bar (Two Required)
5	M147	Gasket (Two Required)
6	R619	Motor
7	11787	Fan Blade
8	DV635	Combustion Chamber
9	11766	Fan Housing
10	11759	Side Panel
11	DV627	Upper Front Panel
12	R1619	Bushing
13	DV823	Diverter Assembly
14	R1749	Vent Safety Switch
15	R1587	Vent Safety Wire Assembly
16	R1536	Bushing
17	11765	Switch Compartment Assembly
18	DV832	Switch Compartment Cover
19	R630	Limit Control
20	R1941	Fan Control
21	DV826	Rear Burner
22	R1617	Spark Plug Wire
23	R714L	Pilot Burner With Orifice LP Gas
23	R714N	Pilot Burner With Orifice Natural Gas
24	DV808	Pilot Tubing
25	DV562	Lower Front Panel
26	DV824	Front Burner
27	P8842	Main Burner Orifice Natural Gas (Two Required)
27	P8853	Main Burner Orifice LP Gas (Two Required)
28	DV687	Manifold and Plate Assembly
29	M148	Manifold Gasket
30	DV064	Cover Plate For Observation Hole

Index No	Part No.	Description
31	DV847	Burner Door Natural Gas
31	DV972	Burner Door LP Gas
32	DV691A	Seal Bracket
33	M147	Gasket Tubing Seal
34	P112	Manifold Union
35	R2147	Gas Valve VR8204C 1126 LP Gas (10.0")
35	R2149	Gas Valve VR8204C 1001 Natural Gas (3.5")
36	UH810	Transformer Mounting Bracket
37	R1995	Transformer
38	UH451	Junction Box Cover
39	DV974	Outer Casing Bottom
40	R1515	Bushing
41	R690	Cord Set
42	R896	Bushing
43	DV671	Manifold Support
44	DV765	Gasket for Chamber Air Inlet (Top & Bottom) (Two Required)
45	DV764	Gasket for Chamber Air Inlet (Sides) (Two Required)
46	R721	Wire Harness
47	R1616	Control Module
48	DV692	Control Module Mounting Bracket
49	R1404	Bushing
50	DV684	Inner Lining Assembly
51	DV629	Casing Back
52	11759	Side Panel
N/S	R9832	Wiring Assembly Upper
N/S	R9833	Wiring Assembly Lower
N/S	P8853	Pilot Orifice LP
N/S	P8842	Pilot Orifice Natural

**USE ONLY MANUFACTURER'S REPLACEMENT PARTS. USE OF ANY OTHER PARTS COULD CAUSE INJURY OR DEATH.**

# PARTS VIEW

