

PARTS LIST

ATTENTION: When ordering parts, it is very important that **part number** and **description** of part coincide.

Index No.	Part No.	Description
1	WFA115	HEADER GASKET
2	36323	HEADER ASSEMBLY (INCLUDES NO. 1, GASKET)
3	GWT182	INNER CASING ASSEMBLY
4	GWT065	DIVERTER ASSEMBLY- GWT-25W-1
4	GWT066	DIVERTER ASSEMBLY - GWT-35W-1
5	R3239	VENT SAFETY SWITCH - GWT-25W-1
5	R3045	VENT SAFETY SWITCH - GWT-35W-1
6	R3038	ECO LEAD ASSEMBLY
7	GWT020	FRONT SHIELD
8	GWT077	HEAT SHIELD
9	26463	EXCHANGER ASSEMBLY - GWT-25W-1
9	26464	EXCHANGER ASSEMBLY- GWT-35W-1
10	GWT070	BURNER BRACKET ASSEMBLY - GWT-25W-1
10	GWT073	BURNER BRACKET ASSEMBLY - GWT-35W-1
11	R5245	GAS VALVE - NAT
11	R5246	GAS VALVE - LP
12	R3031	BURNER (GWT-25W-1 – 3 REQUIRED) (GWT-35W-1 – 4 REQUIRED)
13	P8855	BURNER ORIFICE - GWT-25W-1 NAT (3 REQUIRED)
13	P8865	BURNER ORIFICE - GWT-25W-1 LP (3 REQUIRED)
13	P8854	BURNER ORIFICE - GWT-35W-1 NAT (4 REQUIRED)
13	P8865	BURNER ORIFICE - GWT-35W-1 LP (4 REQUIRED)
14	GWT169	AIR SHUTTER REAR- GWT-25W-1 LPG
14	GWT012	AIR SHUTTER REAR - GWT-35W-1 LPG
15	GWT054	AIR SHUTTER BOTTOM - GWT-25W-1 LP

Index No.	Part No.	Description
15	GWT049	AIR SHUTTER BOTTOM - GWT-35W-1 LP
16	GWT168	AIR SHUTTER FRONT - GWT-25W-1 LP
16	GWT011	AIR SHUTTER FRONT - GWT-35W-1 LP
17	GWT010	BURNER COMPARTMENT FRONT - GWT-25W-1
17	GWT008	BURNER COMPARTMENT FRONT - GWT-35W-1
18	DV064	COVER PLATE
19	R3035	PILOT - LP
19	R3034	PILOT - NAT
20	GWT021	PILOT BRACKET
21	R1054	THERMOPILE
22	GWT186	CASING BRACKET
23	36328	CASING FRONT ASSEMBLY (INCLUDES #24)
24	R3763	MAGNET (2 REQUIRED)
25	36321	CASING DOOR ASSEMBLY
26	R885	NYLON WASHER (2 REQUIRED)
27	23906	VALVE SHIELD
28	36354	CASING ASSEMBLY COMPLETE (INCLUDES #23, #25, & #26)
29	29011	EXCHANGER TUBE SUPORT
N/S	GWT121	PILOT TUBING- GWT-25W-1
N/S	GWT076	PILOT TUBING- GWT-35W-1
N/S	R1089	PILOT ORIFICE (HONEYWELL .009 LP ONLY)
N/S	R1081	PILOT ORIFICE (HONEYWELL .014 NAT ONLY)
N/S	GWT190	HARDWARE PACKAGE

USE ONLY MANUFACTURER'S REPLACEMENT PARTS. USE OF ANY OTHER PARTS COULD CAUSE INJURY OR DEATH.

PARTS VIEW

